

### **VLCP8B service note: 100-1 Repeat function does not work**

When operating the configuration software on computer there is a mistake in text for transmit mode.

For repeat mode (typically volume control) select transmit mode "Sequential"

**Sequential** will send codes repeatedly as long as bottoms is pressed.

There are only two transmit options:

- Repeat (via Sequential select)
- Simultaneous

